

**** For the V-SFT CD-ROM Ver.5.4.18.0 or earlier ****

V-SFT Ver. 5/ Ver. 6 Update Procedure

This document explains how to update your V-SFT
after installing it on a computer using a CD-ROM Ver. 5.4.18.0 or earlier.

Windows Vista/ 7 (32-bit)	Ver. 5.4.11.0~ / Ver. 6.0.0.0~
Windows Vista/ 7 (64-bit)	Ver. 5.4.19.0~ / Ver. 6.0.0.0~
Windows 8 (32-bit, 64-bit)	Ver. 5.4.28.0~ / Ver. 6.0.0.0~
Windows 8.1 (32-bit, 64-bit)	Ver. 5.4.37.0~ / Ver. 6.0.0.0~
Windows 10 (32-bit, 64-bit)	Ver. 5.4.42.0~ / Ver. 6.0.15.0~
Windows 11 (64-bit)	Ver. 5.4.51.0~ / Ver. 6.1.6.0a~

Hakko Electronics Co., Ltd.

The twelfth edition

July 2025

<Preface>

The default installation directory varies in accordance with the version of V-SFT and the OS of your computer. The procedure for installation is different depending on the version of CD-ROM/DVD-ROM.

Ver. 5.4.10.0 or earlier	Ver. 5.4.11.0 or later	Ver. 6
All OSs: C:¥Program Files¥***** V-SFT V5 --- V-SFT Ver. 5 V-SFT V3 --- V-SFT Ver. 3 V6W --- V-SFT Ver. 2/ 1 UG00S-CWV5 --- POD EDITOR Ver. 5 UG00S-CWV4 --- POD EDITOR Ver. 4 UGW --- POD EDITOR Ver. 3	Windows XP-: C:¥Program Files¥V-SFT V5 Windows Vista or later: C:¥MONITOUCH¥V-SFT V5	All OSs: C:¥MONITOUCH * Three folders, "Common", "User", and "V-SFT V6", are created.

* If installing V-SFT Ver. 5 in "C:¥Program Files" on Windows Vista or later, it may not work properly.

<Points to be checked before installing V-SFT or POD EDITOR >

Check both OS in a computer and CD-ROM/ DVD-ROM Version for V-SFT or UG00S-CW, and use the table below to check whether the software can be installed on your PC or not and installation procedure before installing it.

		V-SFT CD-ROM/ DVD-ROM Version		
OS	Windows Vista or later 32-bit	Ver. 2.0.0.0 to 2.2.42.0 Ver. 3.0.0.0 to 3.0.15.0	Ver. 2.2.43.0 to 2.2.45.0 Ver. 3.0.16.0 to 3.0.24.0 Ver. 5.0.0.0 to 5.4.10.0	Ver. 5.4.11.0 or later Ver. 6.0.0.0 or later
	Installation	X	✓ (see page 3)	✓✓ (see page 6)
	Windows Vista or later 64-bit	Ver. 2.2.42.0 or earlier	Ver. 2.2.43.0 to 5.4.18.0	Ver. 5.4.19.0 or later Ver. 6.0.0.0 or later
	Installation	X	✓ (see page 3)	✓✓ (see page 6)

		UG00S-CW CD-ROM Version	
OS	Windows Vista or later 32-bit	Ver. 3.0.0.0 to 3.2.33.0 Ver. 4.0.0.0 to 4.0.10.0	Ver. 4.0.11.0 to 4.0.17.2 Ver. 5.0.0.0 to 5.0.10.3
	Installation	X	
	Windows Vista or later 64-bit	Ver. 3.0.0.0 to 3.2.33.0	
	Installation	X	✓✓ (see page 6)



When using V-SFT Ver. 6, the emulator for the V10 series does not support 32-bit. Use it on a 64-bit OS Windows.

X : This CD-ROM is not compatible. Please purchase the newest version of V-SFT DVD-ROM.

✓ : Install V-SFT or UG00S-CW by following the procedure explained in this manual.

For details, refer to the "Install Procedure" on page 3.

✓✓ : This manual is not necessary for you. Install V-SFT to the PC by following the instructions of the installer. For updating V-SFT, refer to the "Update Procedure" on page 6.

<Installation Procedure>

* Install the V-SFT editor with the authorization of the administrator.

1. Uninstall V-SFT Ver. 5

If V-SFT Ver. 5 is already installed on Windows Vista or later, you have to uninstall V-SFT Ver. 5.

Click the [Start] Menu → [All Programs] → [V-SFTV5] → [Uninstall]. About the details of uninstallation, refer to “V8 series Introductory Manual”.

If V-SFT Ver. 5 is not installed, go to step 2.

2. Run “setup.exe” in the V-SFT/ POD EDITOR CD-ROM

Insert your V-SFT CD-ROM or POD EDITOR CD-ROM in the PC.

When the following dialog is displayed, click “INSTALL”.

Example: V-SFT Ver. 5



3. Changing the installing directory

If your CD-ROM is V-SFT Ver. 5, click "Change..." on the [Choose Destination Location] dialog.

Change the destination from the default "C:\Program Files\V-SFT V5" to as follows:

* If you have V-SFT CD-ROM Ver. 3/2, or POD EDITOR CD-ROM Ver. 5/4, you do not have to change the destination.

However, V-SFT Ver. 3/2 or POD EDITOR Ver. 5/4 installed on Windows Vista or later cannot be used because they may not work properly.

[Destination folder]

< Before change >


C:\Program Files\V-SFT V5

< After change >

C:\MONITOUCH\V-SFT V5


Upper case letters

a space



4. Start installation

In the [Ready to Install the Program] dialog, click [Install] to start the installation.



5. Implementation of update

Upon the completion of the installation in step 4, update V-SFT editor.

Refer to "Update Procedure" on page 6.


<Update Procedure>

* Install the V-SFT editor with authorization of administrator.

- When updating V-SFT to Ver. 6:

Execute “V-SFTV6_Update(V6.x.x.0).EXE” ("x" designates the version number.) downloaded from our website and follow the installer for instructions. The download page is [here](#).


Do not change the destination from the default.



- When updating V-SFT to Ver. 5:

Execute “V-SFT_V54xx0_up.EXE” ("x" designates the version number.) downloaded from our website and follow the installer for instructions. The download page is [here](#).

Do not change the destination from the default.



V-SFT Ver. 6/ Ver. 5 is ready to use on Windows Vista or later once installation is completed.

* For the detailed procedure for installation, see the instruction [“V-SFT Ver.6 Update Procedure”](#) or [“V-SFT Ver.5 Update Procedure”](#).

(Note)

When updating V-SFT to Ver. 6/ Ver. 5, it is necessary to download manuals for the Help menu from our website.

Execute “VSFTV6_Manual_ENG.EXE” or “VSFTV6_Manual_OTHER.EXE” (Chinese Simplified / Chinese Traditional / Korean) or “VSFTV5_Manual.EXE” download from our website and follow the installer for instructions.